Changing the Time on the Danage System

WA are potentially reducing the time for each arrow shot from 40seconds to 30. This is not in the rules but is being trialled, so this is a quick guide to changing the values if you need to.

Change the Time per End in a Normal Program

1. Find the program you want to change
   a. Press **"Menu"** until you find the one with the right set of timing values
   b. If it is not there then press **"'Enter"** when you get to "Menu Group 2" and then keep pressing **"Menu"** to cycle through the additional entries.
2. Press **"Prog"** to change it.

3. Change the correct number
   a. Press **"Enter"** to move a digit to the right
   b. Press **"Prog / +"** or **"Menu / -"** keys to change the digit up or down
   c. When complete the program will be selected.

      T1 = lead in time - this should be reduced to 10 in the picture above
      T2 = shooting time - this is what needs to change from 120/240 to 90/180
      T3 = amber light time – correct at 30 seconds
      SER = Series - number of details
      M = menu (1 or 2) so you can separate the programs you want to use

4. Press **"Start"** to use the program.
5. Keep pressing the Green Button throughout the day!

Changing the Make Up arrow Timing

If you are timing make up arrows using the Danage box then you will also need to change the value of the time allowed for each make up arrow.

1. Find the Setup Menu -> TIME 1 ARROW T2 value you want to change
   a. Press **"Menu"** until you find the "**Set-up Menu**" item and press "**Enter**"
   b. Keep pressing **"Menu"** to cycle through the additional entries until you find "**TIME 1 ARROW T2**" and press "**Prog**"
2. Change this value to the correct number
   a. Press **"Enter"** to move a digit to the right
   b. Press **"Prog / +"** or **"Menu / -"** keys to change the digit up or down
   c. Press **"Enter"** to go back to the menu and